

INSTALLATION INSTRUCTIONS DECORATIVE FIREPLACE FRAME

DECORATIVE FIREPLACE FRAME		
DFF36CPD-1 & DFF36RPD-1 FOR USE ON DVCT36 SERIES FIREPLACES REQUIRES DFF36FPD-1	DFF40CPD-1 & DFF40RPD-1 FOR USE ON DVCT40 SERIES FIREPLACES REQUIRES DFF40FPD-1	DFF50CPD & DFF50RPD FOR USE ON DVCT50 SERIES FIREPLACE REQUIRES DFF50FPD
DFF30CPD-1 & DFF30RPD-1 FOR USE ON DVCT30 SERIES FIREPLACE INSETS REQUIRES DFF30FPD-1	DFF35CPD-1 & DFF35RPD-1 FOR USE ON DVCT35 SERIES FIREPLACE INSETS REQUIRES DFF35FPD-1	

INSTALLATION

Slide top part of trim into frame and swing bottom part against the frame and down.
Center left to right.

